

HIDDEN FUNCTIONS

TAILS / TRUE BYPASS

Unplug the 9V power supply from the Dystopia.

Hold down the **BYPASS** footswitch while you replug the power supply. Wait that the **BYPASS** led blinks 3 times.

You switched from a Tails mode to a True bypass mode and vice versa.

KILL DRY / FULL WET

Same processing as for the Tails / True Bypass mode. But you hold down the **TAP TEMPO** footswitch this time.

OSC TRIMPOT

A second feedback control for the self-oscillation mode. Factory-set to maximum.

SELF-OSCILLATION

Hold down the **TAP TEMPO** footswitch, the **FBK** knob is now replaced by the **OSC** trimpot.



ANASOUNDS

Serial _____

Made by _____

Date _____



Please read the manual before you plug and use this pedal! **Scan me to read the full manual available on our website.**

DESIGNED AND MADE IN FRANCE




9 rue Jean-Baptiste Spinetta, 06000 NICE, FRANCE

ANASOUNDS.COM


UTOPIA DLX




THE MODULATIONS



THE PREAMP



THE UTOPIA DLX



THE CONTROLS

